



HOW TO CREATE A CONFIG FILE:

- 1- Make sure you have a truck that corresponds with the engine type of the config you're trying to set up.
- 2- Go into [Setup>Power]. Set the Auto power off function to something besides "Never".
- 3- Go to [Setup>Devices>Manager] (enter PIN 2222)
- 4- Tap on the first slot ('a') and then click "Add Device..." (if there's something already in there besides "Ford", Remove that entry first)
- 5- Select "Ford" from the list and click "Install"
- 6- Next screen will have one option to choose from. Select "j1962" and click "Ok"
- It will say "Device Added Successfully". Click Ok
- 7- Add the Analog Driver into the second slot (optional), you have to arrow over to the "Other" heading to find it on the list. Make sure no other drivers are on the list (Remove them if so)
- 8- Click "Exit"
- 9- Make sure you're hooked up to the truck with the key on or engine running. Click "Find Signals"
- 10- It should tell you that it found a bunch of signals. Now when you go to gauges, you can add each signal you want individually, however you want (just click on a gauge where you want to put a signal and then it'll pop up your options to fill in that gauge).